# KURYAKYN

## **INSTALLATION INSTRUCTIONS**

#### **RIOT SHIFT PEG, SATIN BLACK**

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

| <b>WARNING</b>   | THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.   |
|------------------|---|
| <b>A</b> CAUTION | THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.  |
| NOTICE           | THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED. |

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

1 Shift Peg

- 1 Hardware Kit. containing:
  - 1 5/16-24 X 1 Hex Head Cap Screw
  - 1 5/16 Internal Lock Washer

#### YOU WILL ALSO NEED:

Large pliers, set of combination wrenches, socket set and ratchet

# **NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- **STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- **STEP 2** Use large plier to remove the existing shift peg; discard the peg; grasp the end of the existing peg and twist it counterclockwise to unthread it from the lever.
- **STEP 3** Refer to PIC 1. Locate provide Shift Peg, Lock Washer, and Hex Head Cap Screw.
- **STEP 4** Refer to PIC 2. Place the washer over the screw. From the inside edge of the shift lever, thread the Screw all the way through the shift lever.

Note: Shift lever may need to be removed from motorcycle to be able to access the inner edge of the lever, for threading the screw. Refer to your service manual for assistance.



PIC 1

# KURYAKYN

### **INSTALLATION INSTRUCTIONS**

### **RIOT SHIFT PEG, SATIN BLACK**

-CONTINUED-

STEP 5

NOTICE

Refer to PIC 3. Thread the Peg onto the Screw; adjust the angle of the Peg; hold the Peg and tighten the Screw.

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.





PIC 3