

INSTALLATION INSTRUCTIONS

TRI-FIN PRIMARY COVER CAP FOR INDIAN®, SATIN BLACK

5727

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|---------------|---|---|
| 1 | Primary Cover | 1 | Hardware Kit, containing: |
| | | 2 | M6 X 1.0 X 12MM Socket Head Cap Screws with Patch |

YOU WILL ALSO NEED:

Metric Hex Set

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Remove existing primary cover cap, hardware, and primary cover pad. Set all aside, it will not be reused.

STEP 3 Refer to PIC 3. Locate the provided Primary Cover. Align and place the cover over the primary cover assembly.



PIC 1



PIC 2



PIC 3

INSTALLATION INSTRUCTIONS

TRI-FIN PRIMARY COVER CAP FOR INDIAN®, SATIN BLACK

5727

-CONTINUED-

- STEP 4** Refer to PIC 4 and 5. Locate the provided two (2) Socket Head Cap Screws. Insert the screws into the mounting holes of the Primary Cover. Fully tighten hardware.

TORQUE VALUE FOR PRIMARY COVER SCREWS:
15 FT-LBS (20NM)

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

