

INSTALLATION INSTRUCTIONS

HEX SHIFT PEG FOR H-D, SATIN BLACK

5911

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|-----------|---|---------------------------------|
| 1 | Shift Peg | 1 | Hardware Kit, containing: |
| | | 1 | 5/16-24 X 1" Hex Head Cap Screw |
| | | 1 | 5/16 Internal Lock Washer |

YOU WILL ALSO NEED:

Hex key set, combination wrench set

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Remove the existing shift peg and hardware; set side it will not be reused.

STEP 3 Refer to PIC 1. Locate provided Shift Peg, Internal Lock Washer, and Hex Head Cap Screw.

Note: Refer to PIC 2. Be sure the metal pin that is located in the provided shift peg is inside of the peg before installing.

STEP 4 Refer to PIC 3. From the inside edge of the shift lever, thread the Screw all the way through the shift lever. Place the washer over the screw. Apply small amount of blue lock tight to threads of the screw.

Note: Shift lever may need to be removed from motorcycle to be able to access the inner edge of the lever, for threading the screw. Refer to your service manual for assistance.

STEP 5 Refer to PIC 4. Thread the Peg onto the Screw; adjust the angle of the Peg. Hold the Peg and tighten the Screw.



PIC 1



PIC 2



PIC 3



PIC 4

INSTALLATION INSTRUCTIONS

HEX SHIFT PEG FOR H-D, SATIN BLACK

5911

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

