



**BLACK ISO-THROTTLE BOSS FOR GL1800 HEATED GRIPS**

**6314**


**THANK YOU FOR CHOOSING KÜRYAKYN!**

**PROTECT YOURSELF AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS. PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS, AND NOTICES REGARDING THE INSTALLATION, USE, AND CARE OF THIS PRODUCT.**

<b>WARNING</b>	<b>THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.</b>
<b>CAUTION</b>	This indication alerts you to the fact that ignoring the contents described herein can result in minor or moderate potential injury.
<b>NOTICE</b>	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

**MAKE SURE THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:**

- 1 Black ISO-Throttle Boss (Right)
- 4 4-40 X 9/16" socket head cap screws
- 1 Installation Instructions



**TOOLS SUGGESTED:**

Set of hex wrenches

**NOTICE** This copy of installation instructions contains important information. Ensure that the end user receives this copy and is aware of its importance for future reference.

- STEP 1** Remove the 4 screws securing the existing end cap to the right-side ISO-Grip. Remove the end cap and trim ring. The screws will not be re-used.
- STEP 2** Place the Black ISO-Throttle Boss against the grip body (PIC 1). Loosely reinstall the end cap with the Throttle-Boss in place using the included 4-40 x 9/16" screws.
- STEP 3** Position the ISO-Throttle Boss where it will be the most comfortable for you at cruising speeds.
- STEP 4** Tighten the mounting screws and check for proper throttle operation.

**NOTICE** It is the end user's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

**CAUTION** Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

*Ride On!*