

INSTALLATION INSTRUCTIONS

PRECISION COOLANT PUMP COVER, GLOSS BLACK

6421

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|--------------------|---|---------------------------------------|
| 1 | Coolant Pump Cover | 1 | Hardware Kit, containing: |
| | | 2 | 1/4"-20 X .625" Socket Head Cap Screw |
| | | 2 | 1/4" Split Lock Washer |

YOU WILL ALSO NEED:

Set of hex wrenches, set of hex bit sockets

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

WARNING A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Remove the existing cover and rubber grommets from the coolant downtube; set them aside they will NOT be reused.

Note: Refer to your motorcycle's user manual for assistance.

STEP 3 Refer to PIC 2 and 3. Locate the provided Coolant Pump Cover. Align the two notches located on the top of the cover with the two hooks located between the coolant pump and the voltage regulator. Slide the cover in and over the hooks. Pull it down to secure it in place.



PIC 1



PIC 2



PIC 3

INSTALLATION INSTRUCTIONS

PRECISION COOLANT PUMP COVER, GLOSS BLACK

6421

-CONTINUED-

- STEP 4** Refer to PIC 4. Locate two (2) provided Socket Head Cap Screws and Split Lock Washers. Thread the washers onto the screws. Insert the screws through the coolant downtube mounting holes and fasten it to the cover. Fully tighten hardware, but be careful not to over tighten.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

