

INSTALLATION INSTRUCTIONS

LUGGAGE RACK FOR SISSY BAR

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

- WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
- CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.
- NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|---------------------------------------|---|-------------------------------|
| 1 | Rack | 1 | Left Rack Mount (clutch side) |
| 4 | 1/4-20 x 0.625 Socket Head Cap Screws | 1 | Right Rack Mount (brake side) |

YOU WILL ALSO NEED:

Hex bit set, in-lbs (Nm) torque wrench

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

THIS LUGGAGE RACK IS INTENDED TO BE USED WITH KURYAKYN PASSENGER BACKRESTS P/N 6581, 6582, 6583, 6584, 6585, 6586, 6587, OR 6588 (SOLD SEPARATELY).

- STEP 2** Located provided rack. Align and place rack on top of the Kuryakyn Passenger Backrest bars near the base.

- STEP 3** Refer to PIC 2. Locate provided Left Rack Mount (clutch side) and two (2) screws. Align and place the mount under the backrest bar. Loosely secure the mount to the rack using the provided screws.

- STEP 4** Locate provided Right Rack Mount and two (2) screws. Repeat step 3 for the right (brake) side.

- STEP 5** Fully tighten all hardware.

TORQUE VALUE FOR LUGGAGE RACK MOUNT SCREWS:
76 IN-LBS (8.6 Nm)

