

INSTALLATION INSTRUCTIONS

DILLINGER HEADLIGHT TRIM RING, 5-3/4", SILVER

6687

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Headlight Trim Ring

YOU WILL ALSO NEED:

Hex wrench set

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

Note: Before installation of the new trim ring, you may want to fully clean your headlight.

- STEP 2** Refer to PIC 1 through 3. Locate provided Headlight Trim Ring. Remove the hardware from each side of the trim ring, and separate the halves.

Note: Be aware that the headlight guard is a separate piece and is not attached to either of the trim rings. Be sure it is properly set in one of the trim rings before installation.

- STEP 3** Refer to PIC 4. Align and place the trim ring with the inserted headlight guard over the bottom side of the headlight.

- STEP 4** Refer to PIC 5. Align and place the other trim ring over the top of the headlight. Be sure the mounting holes of the trim rings align.



INSTALLATION INSTRUCTIONS

DILLINGER HEADLIGHT TRIM RING, 5-3/4", SILVER

6687

-CONTINUED-

STEP 5

Refer to PIC 6. Locate the hardware that was removed from the trim ring, in Step 2. Insert the socket head screws through the top of the mounting holes, and the lock nuts on the bottom half. Evenly tighten the hardware on each side of the trim, until it is fully secured in place.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 6



FINAL