

Rim Lock Damper, 11-0076

PAD INSTALLATION

Remove adhesive backing and install pad over LiteLoc™ bolt with adhesive facing rim lock. The foam pad works as a dampening device to inhibit spokes from loosening and to keep LiteLoc™ properly aligned in rim hole.

