


PWSAK-Y20-421



Qty.	Part Number	Description
4	Y-BE-001	Bearing
2	Y-SE-005	Oil Seal
2	ZTBE-001-KSY	Bearing
4	ZTW-001-SY	Bearing
2	Y-SE-008	Oil Seal
2	Y-CL-003	Collar
2	Y-PI-027	Collar