




PSM11013

















MOUNTING THE MAGICPLATE™

OPTION 1 (small or large plate)

Attach adhesive side of metal plate directly to back of device





OPTION 3 (large plate only) Attach adhesive side of metal plate to interior of case, between device and inside of case. Plate will adhere to magnetic mount through rear panel of case.

NOTE: If you choose not to attach the metal plate to the device or case please leave the adhesive backing in place. Position the plate between the device and interior of case with the metal surface facing the case.


OPTION 2 (small or large plate)

Attach adhesive side of metal plate directly to back of case





MAGICPLATE[™] PLACEMENT



For Typical Smartphones


qi I

For Wireless Charging Qi-enabled Smartphones

REMOVING THE MAGICPLATE™

Use a thin plastic card to carefully lift the plate's adhesive surface from the mounting surface. Slowly lift up and remove the plate.

ASSEMBLY




INSTRUCTIONS

- 1. Install MAGICMOUNT[™] ball into the elastic center ring and hook into place (A*)
- 2. Mount MAGICMOUNT[™] assembly (B) along with the two mounting adapters (C) to the extension bar (D)
- **3.** Insert the top tightening knob through one of the washers and tighten into the Magic Mount adapter assembly (**E**).
- 4. Assemble the fork stem adapter in the following order:
 - Screw through washer and into top of ball joint.
 - Ball joint assembly into base slot and insert another washer through the screw.
 - Select appropriate size expander and tighten into place.
- 5. Select the fork stem mounting location and tighten using an Allen key. Once the expander is secured, mount the top Magic Mount assembly (F) using the last two adapters, (1) tightening knob and (1) washer by doing the same process executed on step two (G).

SET-UP GUIDE


Elastic Band

With the metal plate positioned onto the device, align the elastic band with your device and attach to the corners of your device as shown (A). The elastic band will secure your device while riding.



Fork Stem Angle Adjustment


To reposition the angle of the fork stem first loosen the tightening knob (E). Next, reposition the angle of the bar in the position wanted (F). Once the position is set, tighten the knob (E) to secure the desired angle of the bar extension.



GUIDE NOTE: Elastic band can be positioned horizontally or vertically

Assembling Fork Stem

Insert the screw through one of the washers provided **(B)**. Second, insert the screw assembly through top of the ball joint **(C)**. Third, place the ball joint assembly onto base adapter **(D)** and insert the second washer through the extruded screw thread. Lastly, select the appropriate size expander and temporarily hand tighten into place until mounting onto location.



Magic Mount Adjustment

Loosen knob (G) to reposition the angle of the **MAGIC**MOUN[™] up to 360° (H). Once the position is set, tighten the knob (G) to secure the positioning **MAGIC**MOUNT[™].

NOTE: When loosened the angle of the mount is capable of 360° rotation for positioning.