



SENA 3S Quick Start Guide

Boom Microphone Type




Battery Check




Button Operation




Power On/Off




Volume Adjust





Configuration Menu



Start/End Intercom





Bluetooth Pairing Phone, MP3, GPS




Enter PIN




Headset Pairing Intercom



Music



Mobile Phone



Note:
Voice Dial and Redial functions are available only in stand-by mode and not available during music playback.

