



Lighter Pouches

Zippo's lighter pouches are the perfect accessory for those who want their Zippo windproof lighter handy at all times. The pouches protect the lighters finish and connect to your belt so that you can take your favorite lighter anywhere. There are two styles of pouches to choose from; the genuine leather pouches and the paracord pouch. Select from four different pouch types; loop, clip, thumb notch, and belt clip & loop.

Types of Pouches:



Loop

The loop feature on this pouch fits belts up to 2 inches wide while holding any Zippo windproof lighter securely.



Clip

This clip feature on this pouch will hook on to any belts, waistbands or pocket while holding any Zippo windproof lighter securely.



Thumb Notch

The thumb notch feature on this pouch allows for easy removal of any Zippo lighter. The wide leather loop fits belts up to 2 inches wide and will hold any Zippo lighter securely.



Belt and Clip Loop

The belt loop will fit belts up to 2 inches wide while securing a standard-size Zippo lighter in place. The clip loop is great to use to attach the pouch to backpacks or belts.



Paracord Pouch

This pouch is ready for anything. Designed with versatility in mind, this pouch provides 26 feet of paracord that can be used for countless emergency or survival situations. Made from 5mm woven nylon rope this pouch also features a button to secure a standard-sized Zippo lighter and belt loop and clip loop to attach to pants or backpacks. The features of this pouch include:

- 5mm woven nylon
- 450 lbs. break strength *not for climbing or descending
- Button closure
- 26 feet unraveled
- Belt and clip loops



Z-Clip

The Zippo Z-Clip keeps your Zippo lighter handy. Features of the Z-Clip include a sturdy black plastic unit that clips onto belts, waistbands, pockets, or sun visors. Holds your Zippo windproof lighter securely, yet is easily accessible.

Fits standard size Zippo lighters only. Does not fit Slim® lighters.