

Instructions – PMB-01-3003

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

1-8x30 FH

1-8x70 SH

1-8x20x30 Spacer

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the stock kickstand and all kickstand brackets, if applicable.
2. Remove the lower chain roller or slide bolt, make sure you keep track of the order of the small parts for re-assembly. Remove the sub-frame to main-frame bolt.
3. Install the kickstand on the bike using the 8x30mm flat head bolt at the sub-frame to main-frame bolt location.
4. Line up and install the provided spacer and 8x70mm socket head, into the lower mounting bracket. Install the chain roller or slide at this time if it was removed. Make sure that there is proper clearance on the length of the bolt.
5. Tighten all bolts to the correct torque as specified in your owner's manual.
6. Periodically check the kickstand leg pivot bolt and all mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.