

INSTALLATION INSTRUCTIONS

CRUISER FOOTREST BOARDS Part # 21-330, #21-330C, #21-351, #21-351B, 21-553B

TOOLS REQUIRED: 8MM ALLEN WRENCH

14MM SOCKET & WRENCH

1. THIS PART IS SUPPLIED WITH TWO (2) DIFFERENT SIZE BOLTS.

2. USE BOLT SIZE M10 – 1.25 X 65 WHEN ATTACHING THE FOOTREST BOARD ONTO THE FOLLOWING PARTS:

#21-301 1" UNIVERSAL CLAMP

#21-302 1" CLAMP (VALKYRIE INTERSTATE)

#21-303 1 1/4" UNIVERSAL CLAMP

#21-351 PASSENGER PEG RELOCATOR

#21-352 DRIVER PEG RELOCATOR

#21-552 PASSENGER PEG RELOCATOR

#21-553 PASSENGER PEG RELOCATOR

3. USE BOLT SIZE M10 – 1.25 X 75 WITH LOCK NUT WHEN ATTACHING THE FOOTREST BOARD ONTO THE FOLLOWING PARTS:

#21-310 STRAIGHT OFFSET EXTENSION

#21-312 STEPPED OFFSET EXTENSION

NOTE: WE RECOMMEND USING "LOCTITE" ON THE THREADS OF THE BOLTS THAT DO NOT UTILIZE LOCK NUTS.