



INSTALLATION INSTRUCTIONS

HONDA CB1000R 2018-

© by MRA-Klement GmbH – 06/2018 4025066163274

INSTALLATION INSTRUCTIONS

Honda CB1000R 2018-

Thank you for buying a MRA Windshield.


Read this manual carefully and check the parts list for completeness before you begin. We recommend that you have your screen fitted by an authorised workshop.

Number	Article	Article No..	Required tools
1	MRA windscreen	---	Allen key 3 + 5mm
1	Pair of retaining plates	11340	Torx 40
4	Elastic nuts M5	10629	
4	Plastic washers 12x5x0.5mm	10635	
4	Filister head screws, black, M5x16mm	10554	


Fitting the screen to the motorcycle:

1. Place the motorcycle on a flat surface.
2. Remove the fixing screws from the headlight (P1).
3. Carefully fold the headlight forwards and pull it out from the rubber support.
4. Separate the headlight from the cable harness and lay it to one side.
5. Remove both Allen screws (P2), attach the retaining plates [11340] to the motorbike with the original Allen screws (P3 & P4). Take care to ensure that the retaining plates are attached exactly as is shown in Image 3: there should be enough space between the light holder and the retaining plates to reattach the headlight.
6. When the retaining plate is aligned correctly, firmly tighten the Allen screws.
7. Now connect the headlight to the cable harness again and reinstall it below in the rubber support. Fold up the headlight and secure it with the retaining plates and the original Torx screws (P5).
8. Now plug the elastic nuts [10629] into the retaining plates (P5) and attach the MRA windscreen with the plastic washers [10635] and the provided M5x16 filister head screws [10554] to the retaining plate.
9. Pull the protective edge strip onto the windscreen as shown in Image 6 and then cut off the rest, if necessary.
10. Push the clamping sleeves over the ends of the protective edge strip and lightly compress them, using a pair of universal pliers to clamp the edge strip.

After installation, check that all of the screws are tight; tighten them up if necessary. Repeat this at regular intervals. Clean the screen with water, neutral soap and a sponge. Do not use solvents, alcohol or spirits to clean the screen as they will damage it.




P 1




P 2



P 3



P 4



P 5



P 6