

EE Radiator Brace Instructions



FIG 1



FIG 2



FIG 3



FIG 3a



FIG 4



FIG 5



FIG 6




FIG 7



FIG 8



FIG 9




FIG 10



FIG 11



FIG 12



FIG 13



FIG 14



FIG 15

- 1** Remove the seat (Fig. 1).
- 2** Remove the tank and shrouds (Fig. 2).
- 3** Drain the coolant (Fig. 3).
- 3a** **NOTE:** you will need to remove the radiator cap to allow the coolant to fully drain.
- 3b** Once the coolant is drained, be sure to reinstall the drain bolt.
- 4** Using an 8mm T-handle or socket, remove the two mounting bolts for the radiator and louver. (Fig. 4).
- 5** Loosen the top radiator hose clamp only, and disconnect the radiator from the hose (Fig. 5).
- 6** With the supplied M6x16mm button head bolts attach the 2 supplied radiator rods to the part labeled 017R/L1 (right or left side) (Fig. 6).
- 7** Install the supplied rubber bumper to the side of the 017R/L1 with the supplied 6x8mm button head bolt. (Fig 7).
- 8** Position the 017R/L1 assembly between the frame and the radiator (Fig. 8).
- 9** Slide the radiator back onto the upper hose and tighten the hose clamp.
- 10** Set the radiator louver back into position (make sure the louver is in the groove on the outside of the radiator).
- 11** Using the supplied M6x16mm flange bolts, attach part 017R/L2 on the frame over the louver. (do not fully tighten yet) (Fig 9).
- 12** With the 3 supplied M6x10mm button head bolts attach part 017R/L2 to part 017R/L1 (Fig 10).
- 13** Now tighten the M6x16mm flange bolts to the frame making sure that the louver is over the top of the posts on the frame so that the part 017R/L3 lands flat on the top of the posts.
- 14** **For EXC models that have a fan**, unbolt the fan bracket from the radiator and then remove the fan from the bracket. Attach the fan to part 017R3 using 3 of the original screws. (Fig. 11).
- 15** Using the supplied M6x16mm button head bolts attach the part labeled 017R/L3 to the outside of the rods (Fig. 12).
- 15a** Use the supplied M6x8mm button head bolts to connect the back side of the two pieces together (Fig. 13).
- 15b** Tighten all fasteners
- 16** Use the supplied rubber straps to secure your radiator shrouds (Fig. 14).
- OPTIONAL:** If you would like the shrouds to fit tighter to the radiator, using a 3/8" drill bit, drill a hole on the outside edge of each factory hole (Fig 15).
- 17** Repeat steps 4-11 on the opposite side of the bike.
- 18** Replenish the coolant.
- 19** **NOTE:** Put the seat back on.
- 20** Have fun and ride safe!

WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Enduro Engineering, Inc. (EEI) are to be installed by a licensed motorcycle dealer or a licensed motorcycle technician. Motorcycles can be dangerous. Serious injury, death and property damage can result from the use of motorcycles. This risk is increased by improper installation or misuse of after market parts. EEI's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by EEI, the responsibility of EEI is limited to either a refund of the purchase price or the replacement of the part if EEI determines the part to be defective, and subject to EEI's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to EEI products will void this limited warranty). EEI, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever. By purchasing an EEI product or a product sold by EEI, you (1) acknowledge the above disclaimer and agree to its terms; (2) agree that any claim brought against EEI arising from and/or pertaining to or otherwise related to a part manufactured, designed or sold by EEI must be brought in the Michigan State Courts located in the County of Ingham or in the Federal District Court for the Western District of Michigan and that Michigan law shall apply on all issues; and (3) any claim against EEI must be brought within one (1) year of purchase of the product. EEI makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose. R.JRF.Sec.randt.warninganddisclaimer. 5 2 08



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Radiator Brace Instructions

Part# 11-017