



## Instructions – PMB-01-1007

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

### **Parts List:**

1-Kickstand

**NOTE:** We recommend using a thread-locking agent on all bolt threads.

### **To install your new kickstand:**

1. Remove the left footpeg and bracket and existing footpeg/kickstand bracket from the frame.
2. Install the kickstand under the left footpeg bracket using the stock bolts. We recommend using a removable thread-locking agent on the bolts. Check to make sure that the weld on the frame is not interfering with the kickstand mount; if necessary file the bracket to allow for proper fit.

**NOTE: Clearance will be required on 125/250 2-stroke models.**

3. Make sure that you tighten the footpeg bracket bolts to the correct torque specification.
4. Re-install the footpeg.
5. Periodically check the footpeg mounting bolts and kickstand pivot bolt for tightness.

### **To prevent damage:**

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.