



FSY-14R6-K

Diamond Frame Sliders Yamaha R6 (2008-2015)

PARTS LIST

- | | | | |
|---|---|-----------------------------|---|
| • M10 x 70 Hex Bolts | 2 | • Right Side (Thinner) Puck | 1 |
| • 10m Press-In Spacer (installed in puck) | 1 | • Left Side Bracket | 1 |
| • 7m Press-In Spacer (installed in puck) | 1 | • Right Side Bracket | 1 |
| • Left Side (Thicker) Puck | 1 | | |

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

ATTENTION: INSTALL ONE SIDE AT A TIME

DO NOT REMOVE BOTH engine mount bolts from both sides of the motorcycle at the same time!

RIGHT SIDE INSTALLATION

- 1) Remove the right side fairing from the motorcycle.
- 2) Remove the bolt, shown in the **photo 1**, attaching the upper fairings to the frame



PHOTO 1

- 3) Remove the right side engine mount bolt. Keep the stock spacer in the mount hole.
- 4) Install the right bracket making sure the large hole in the end is around the protruding bolt mount for the upper fairing, where the bolt is removed.
- 5) Install one of the supplied M10 x 70 hex bolts through the right side (thinner) slider puck with the installed press-in spacer.
- 6) Apply a thread locking compound onto the threads of the bolt. Install the frame slider assembly into the bracket, locating the puck on the bracket's pin, and through the spacer kept from step 3. Torque the bolt to 40Nm / 28.8ft lbs.
- 7) Reinstall the right side fairing.

LEFT SIDE INSTALLATION

- 1) Remove the left side fairing from the motorcycle.
- 2) Remove the bolt, shown in the **photo 1**, attaching the upper fairings to the frame.
- 3) Remove the left side engine mount bolt.
- 4) Install the left bracket making sure the large hole in the end is around the protruding bolt mount for the upper fairing, where the bolt is removed.
- 5) Install one of the supplied M10 x 70 hex bolts through the left side (thicker) slider puck with the installed press-in spacer.
- 6) Apply a thread locking compound onto the threads of the bolt. Install the frame slider assembly into the bracket, locating the puck on the bracket's pin. Torque the bolt to 40Nm / 28.8ft lbs.
- 7) Reinstall the left side fairing.

For Race

&

Street



The purchaser releases Graves Motorsports, Inc from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident. **This product is intended for Closed Course Competition Use Only** and may render the vehicle illegal for use on public roads.