



PLUG-N-GO DRIVER BACKREST WITH BLACK PAD

1628

Thank You For Choosing Kuryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 4 M6 X 1.0 X 25 MM Socket Head Cap Screws
- 4 M6 Flat Washers
- 4 M6 Split Lockwashers
- 2 Spacers
- 1 Set Screw
- 1 Cable Tie

YOU WILL ALSO NEED:

Set of Metric hex wrenches, set of open end wrenches, socket set and ratchet, FT LBS (Nm) torque wrench

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

- STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**. Allow the engine and exhaust system to cool.

WARNING

BEFORE RIDING, ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE.


- STEP 2 Read and understand all STEPS in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**.

- STEP 3 Remove the seat. Disconnect any wiring before fully removing the seat.

- STEP 4 Roadmaster only: Refer to PIC 1. Remove the two (2) existing screws from the passenger grab-strap bracket.


- STEP 5 Remove the brake-side (right hand) screw shown in PIC 1.

- STEP 6 Locate the included Hardware Kit. Assemble the four (4) included Screws, Split Lockwashers, and Flat Washers as shown in PIC 2; set them within arm's reach of the work area.






- STEP 7 All except Roadmaster: Position the two (2) included Spacers over the holes shown in PIC 3.
- STEP 8 Position the included Backrest Receiver over the threaded holes (and spacers); align the holes and secure with the four (4) Screws with Washers. Torque the Screws to 7.5 FT LBS (10.2 Nm).
- STEP 9 Insert the included Cable Tie through the small hole on the left side of the Receiver; secure the wiring with the Cable Tie.
- STEP 10 Slide the included Backrest into the Receiver.
- STEP 11 Locate the included Set Screw; thread it into the Receiver until it contacts the Backrest upright; turn the Set Screw counterclockwise two full turns. The Set Screw applies tension to the Backrest to keep it in place during use while allowing removal without using tools. Remove and replace the Backrest a few times to ensure that it will remain in place; adjust the Set Screw as necessary. Remove the Backrest from the Receiver.




- STEP 12 Refer to PIC 4. Loosen the four (4) hex head screws on the sides of the Receiver; loosen the two small set screws below the hex head screws.



NOTE: In the following STEP you will be adjusting the fore/aft position of the Backrest. Additional Adjustment: Pull the Backrest pouch off, flip the upright over, and reinstall the pouch.

- STEP 13 Refer to PIC 5. Temporarily reinstall the seat; slide the Backrest through the seat and into the Receiver. Sit on the motorcycle and adjust the Backrest height and fore/aft position to your liking; dismount the motorcycle; carefully remove the Backrest from the Receiver; remove the seat.
- STEP 14 Tighten the four (4) hex head screws; tighten the two small set screws.
- STEP 15 Reinstall the seat; reinsert the Backrest through the seat and into the Receiver.



NOTICE

It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.