



COVER FOR GL 1800 TIMING CHAIN COVER **3909**

PARTS INCLUDED

- 1 Timing Chain Cover with Adhesive
- 1 Timing Hole Cap
- 4 Alcohol Pads
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Metric Sockets with Ratchet, Torque Wrench (ft/lb)


STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Remove the original equipment timing hole cap (PIC.1) with the 17mm socket and ratchet.

STEP 3 Install the original equipment o-ring on the new, chrome cap. The o-ring should be on the stock cap, but it may have stuck to the timing chain cover.



-cont.-

STEP 4 Apply grease to the threads of the new chrome timing hole cap and coat the o-ring with engine oil. Install the cap and torque to 13 ft./lbs.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

STEP 5 Test fit the Timing Chain Cover. Make any reference marks with a non-permanent marker or masking tape.

STEP 6 Remove any grease or debris from the OEM timing chain cover with soapy water and a clean rag; allow the area to dry completely. Clean the OEM timing chain cover with the included alcohol pads to remove any residue. Allow the installation area to dry.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 7 Rub the backing on the adhesive strips on the back of the new Timing Chain Cover to activate the adhesive before applying. Remove the adhesive backing. Center the Timing Chain Cover over the Timing Hole Cap installed in Step 4 and press it into place for one minute to ensure proper adhesion. PIC 2 Full bond strength will occur within 24 hours.

STEP 8 Start the bike and allow it to run until it reaches normal operating temperature. After idling for five minutes at normal operating temperature, turn the bike off and allow it to sit over-night (10-12 hours).

PIC 2

