

INSTALLATION INSTRUCTIONS

ROTOR COVERS FOR GL1800 & F6B, GLOSS BLACK

7460

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | |
|---|---|--|
| 1 | Right Rotor Cover | Hardware Kit, continued: |
| 1 | Left Rotor Cover | 2 M6 x 1.0 x 13mm Socket Head Cap Screw |
| 1 | Hardware Kit, containing: | 4 M6 x 1.0 x 23mm Button Socket Cap Screw w/8mm Shoulder |
| 1 | Right Triangle Bracket | 2 Wave Washers |
| 1 | Left Triangle Bracket | 8 Rubber Washers |
| 3 | M6 x 1.0 x 30mm Button Socket Cap Screw | 1 M6 X 1.0 Flange Lock Nut |
| 1 | M6 x 1.0 x 35mm Button Socket Cap Screw | |

YOU WILL ALSO NEED:


Metric Hex Set, Metric Socket Set, Ft-Lbs (Nm) Torque Wrench, Combination Wrench Set, Blue Loctite

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.



- STEP 2** Refer to PIC 2. Remove the hardware from the rear-end of the front fender covers. Set hardware aside, it will be reused.



- STEP 3** Refer to PIC 3. Removed the hardware on the front Fender. Set hardware aside, it will NOT be reused.

INSTALLATION INSTRUCTIONS

ROTOR COVERS FOR GL1800 & F6B, GLOSS BLACK

7460

-CONTINUED-

STEP 4 Refer to PIC 4. Remove the front fender cover. Set it aside, it will be reused.

STEP 5 Remove the two (2) OEM pinch bolts from the bottom of the fork slider. Set bolts aside, they will be reused.

Note: Complete steps 5 and 6 one side (left or right) at a time.

STEP 6 Refer to PIC 4 and 5. Locate the provided Left (L) and Right (R) Triangle Bracket and the two (2) OEM pinch bolts removed in step 5. Apply a small amount of Blue Loctite to each OEM pinch bolt. Align and fasten the bracket to the bottom of the fork slider using the OEM bolts.

TORQUE VALUE OF PINCH BOLTS:
16 FT-LBS (22NM)

STEP 7 Locate provided Left and Right Rotor Covers, two (2) M6 X 1.0 X 13mm Socket Head Cap Screw, and two (2) Wave Washer. Place a washer onto each of the screws.

STEP 8 Loosen the three (3) pre-attached button socket cap screws located on the bottom edge of the Rotor Cover.

STEP 9 Refer to PIC 7 and 8. Using a ball-end metric hex key, insert the key through the bottom rear slot of the Rotor Cover. Place the socket screw and wave washer assembly on the end of the hex key, and align the cover with the bracket attached to the bottom of the fork slider. Loosely fasten the screw to the rear-end mounting hole of the triangle bracket.

STEP 10 Locate provided two (2) M6 x 1.0 x 30mm Button Socket Cap Screws and two (2) Rubber Washers. Place a washer onto each of the screws.

STEP 11 Refer to PIC 9. Insert the 30mm screw and washer assembly into the lower front mounting hole of the rotor cover, that aligns with the front mounting hole of the bracket. Lightly tighten hardware.

STEP 12 FOR RIGHT (BRAKE) SIDE INSTALLATION ONLY
Refer to PIC 9. Locate provided one (1) M6 x 1.0 x 30mm Button Socket Cap Screw and one (1) Rubber Washers. Place the washer onto the screw.

Insert the screw and washer assembly into the rear top left mounting hole of the rotor cover, that aligns with the mounting hole of the lower fork case assembly. Fully tighten the 30mm button screws, the socket screw from step 9, and the three (3) pre-attached bottom edge button screws from step 8.


Note: Be sure the brake line is safely fastened in it's retaining clip on the outside edge of the fork case assembly.



PIC 4



PIC 5




PIC 6



PIC 7



PIC 8



PIC 9

INSTALLATION INSTRUCTIONS

ROTOR COVERS FOR GL1800 & F6B, GLOSS BLACK

7460

-CONTINUED-

STEP 13 FOR LEFT (CLUTCH) SIDE INSTALLATION ONLY

Locate provided one (1) M6 x 1.0 x 35mm Button Socket Cap Screw, one (1) Rubber Washer, and one (1) Lock Nut. Place the washer onto the screw.

Insert the screw and washer assembly into the rear top right mounting hole of the rotor cover, that aligns with the mounting hole of the lower fork case assembly. Align the lock nut on the backside of the fork case assembly, and fasten onto the protruding screw. Fully tighten the 30mm and 35mm button screws, the socket screw from step 9, and the three (3) pre-attached bottom edge button screws from step 8.

STEP 14 Locate provided four (4) M6 x 1.0 x 23mm Button Socket Cap Screw w/8mm Shoulder, and four (4) OEM screws that were removed in step 2.

STEP 15 Refer to PIC 10. Align the mounting holes of the front fender cover with the front fender and rotor cover. Fasten the cover by using the 23mm screws in the front two (2) mounting holes, and the OEM screws in the two (2) rear mounting holes. Fully tighten hardware.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

