



KURYAKYN'S DELUXE WOLO BAD BOY AIR HORN KIT 7742

PARTS INCLUDED

- 1 Wolo Bad Boy Air Horn
- 1 Wiring Harness
- 1 Horn Mount Kit:
- 1 Mount, black
- 1 5/16"-18 x 3/4" Socket Head Cap Screw
- 1 5/16"-18 Nylon Insert Lock Nut
- 1 Hot Spot Bolt Cap, 5/16"
- 6 6" Cable Ties, Black
- 1 Installation Instruction

Please read and understand entire instructions before starting installation

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Hex Wrenches, Torx Drivers, Combination Wrenches, Phillips Screwdriver

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Attach the black Mounting Bracket to the Deluxe Horn with the 5/16"-18 x 3/4" Socket Head Cap Screw and the 5/16"-18 Nylon Insert Lock Nut. Fully tighten fasteners. PIC 1

STEP 3 Once fastener is fully tightened, place the 5/16" Hot Spot into the head of the Socket Head Cap Screw.

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to: control modules, wiring, chrome & other components.
 - Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

STEP 4 Remove the acorn nut and washer that secures the cowbell horn and cover to the bike. Retain acorn nut and washer for reinstallation. Disconnect the lead wires from the horn, located on the bottom side of the horn. Fully remove the horn from the bike.

STEP 5 Remove the seat or access panel to get to the battery. Connect the ring terminals on the new Horn Wiring Harness to the battery, red wire to positive and black wire to negative. PIC 2

ATTENTION! Secure all wiring away from any moving parts, pinch points or extreme heat. Kuryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

STEP 6 Route the wires under the fuel tank to the horn mount.

STEP 7 Secure the wiring harness with the provided cable ties. Be certain the wires are away from any pinch points or direct heat.

STEP 8 Connect the yellow wire from the new Harness to the yellow wire on the stock wiring harness. PIC 2

STEP 9 Secure the new Horn, with the mounting bracket installed, to the bike with the stock washer and acorn nut (removed in Step 4)
See Note Below. The horn will have a tight fit on the stock rubber grommet. Fully tighten the stock acorn nut.

NOTE: On carbureted models the horn and mounting bracket will need to be rotated on the rubber grommet so the bottom of the horn is angled slightly forward for clearance of the choke knob. PIC 3

STEP 10 Connect the remaining wiring on the Wiring Harness to the Horn. The white wire connects to the positive or rear spade connector. The black wire, from the bike harness, connects to the front negative spade.

STEP 11 Under the seat, plug the horn relay on the new wiring harness to the relay connector located a few inches from the battery terminals.

NOTE: Wrapping the joint between the relay and the relay plug with electrical tape will help keep water and debris out.

ATTENTION! Secure the relay in a location so the terminals face down and it is protected from the elements (road grime, rain, or washing the bike).

STEP 12 With the relay in place, turn the key to check the horn function with the OEM handlebar mounted horn button. If you do not have horn function, review all connections.

STEP 13 Replace the seat or access panel over the battery.

STEP 14 Tighten all fasteners.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

