



DELUXE NECK COVERS

8146

PARTS INCLUDED

- 1 Left Neck Cover
- 1 Right Neck Cover
- 2 Clamp
- 2 Down Tube Cover
- 1 Hardware Kit Including:
 - 1 #10-24 x 5/8" Socket Head Cap Screw
 - 2 5/16" Flat Washers
 - 2 5/16"-18 x 1" Button Socket Cap Screws
 - 4 #8-32 x 1/2" Socket Head Cap Screws
 - 4 #8 Split Lock Washers
 - 1 #10 Split Lock Washer
 - 2 14" Black Cable Ties
 - 2 Rubber Fork Stops
 - 2 1" x 3-1/2" Foam Adhesive Pads
 - 2 3/4" x 1-1/2" Foam Adhesive Pads
 - 1 5/16"-18 X 5-1/2" Stud
 - 2 5/16"-18 Low Crown Acorn Nuts
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING	THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTICE	IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.
---------------	---

TOOLS SUGGESTED

Set of Hex Wrenches, Combination Wrenches, Socket Set and Ratchet

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

WARNING	YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.
----------------	---

NOTICE	Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.
---------------	--

NOTICE


Ensure the area of installation is free of grease, oil, dirt or other debris including wax/polish products and bugs to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

NOTICE

The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 2 Install the supplied foam adhesive pads on the inner surfaces of the covers as shown in PIC 1. Do not remove the inward facing paper from the pads adhered to the lower legs of the cover, as the cover should not be “stuck” to the frame. The pads are meant as an anti-vibration device.

STEP 3 Remove the stock 5/16”–18 fastener securing the front of the fuel tank on the right side.




PROCEDURE FOR '98-'05

STEP 4 Hold the right side cover in place on the neck and frame. Make sure the wiring harness and the throttle control cables run safely between the cover and the frame without being compromised. Loosely secure the right side cover with a supplied 5/16”–18 x 1” Button Socket Cap Screw and a 5/16” Flat Washer that the OEM fastener was removed in STEP 3.

STEP 5 Remove the stock 5/16”–18 fastener securing the front of the fuel tank on the left side.

STEP 6 Hold the left cover in place on the neck and frame. Loosely secure the cover using a supplied 5/16”–18 x 5/8” socket head cap screw and a 5/16” Flat Washer where the OEM fastener was removed in STEP 5.

STEP 7 On the right and left frame down tubes below the lower clamp portion of the neck cover, snap the down tube covers in place. Be sure the clamp portion of the neck cover will slightly overlap the down tube cover.



STEP 8 On the top of the right side cover you will find a fastener hole. Loosely secure the cover halves to each other through this hole using the supplied #10–24 x 5/8” Socket Head Cap Screw with the #10 Split Lock Washer.

STEP 9 On the lower legs of both the left and right side, loosely install the clamps using the supplied #8–32 x 1/2” Socket Head cap Screws with the #8 Split Lock Washers. Make sure the clamps are in the correct orientation so they match the tapered edge of the lower legs.

STEP 10 Slip a rubber fork stop bumper over the stock fork stop “donut” (located on the fork tube) on the right side of the bike and secure it using one of the supplied nylon zip ties. Adding this extra cushion on the left side is usually not necessary and may interfere with fork stop operation.

STEP 11 Starting with the 5/16”–18 x 1” Button Socket Cap Screw (tank mount), tighten all seven fasteners securely.

STEP 12 Turn handlebars in both directions to their full stop position to make sure that the clutch cable, throttle cables, wiring or any other component of the motorcycle, is not stretched or pinched.

WARNING

ENSURE THAT THE CLUTCH CABLE, THROTTLE CABLES, WIRING OR ANY OTHER COMPONENT OF THE MOTORCYCLE IS NOT PINCHED OR STRETCHED AT ANY POINT WHEN THE HANDLEBARS ARE TURNED TO THEIR FULL STOP POSITION ON EITHER SIDE. STRETCHED OR PINCHED COMPONENTS CAN CAUSE LOSS OF CONTROL THAT COULD RESULT IN SERIOUS INJURY OR DEATH.

-cont.-

NOTICE

Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

PROCEDURE FOR '95-'97 MODELS

- STEP 3** Remove the stock 5/16"-18 x 5" bolt and nut securing the front of the fuel tank.
- STEP 4** Hold the right side cover in place on the neck and frame. Make sure the wiring harness and the throttle control cables run safely between the cover and the frame without being compromised. Insert the supplied 5/16"-18 x 5-1/2" Stud through the cover, tank tab and the mounting hole. Hold the Left side cover in place being sure that an equal length of the stud is protruding through the covers on both sides of the bike. Loosely secure both side covers using the supplied 5/16" Flat Washers and 5/16"-18 Low Crown Acorn Nuts.
- STEP 5** On the right and left frame down tubes below the lower clamp portion of the neck cover, snap the down tube covers in place. Be sure the clamp portion of the neck cover will slightly over lap the down tube cover.
- STEP 6** On the top of the right side cover you will find a fastener hole. Loosely secure the cover halves to each other through this hole using the supplied #10-24 x 5/8" Socket Head Cap Screw with the #10 Split Lock Washer.
- STEP 7** On the lower legs of both the left and right side, loosely install the clamps using the supplied #8-32 x 1/2" Socket Head cap Screws with the #8 Split Lock Washers. Make sure the clamps are in the correct orientation so they match the tapered edge of the lower legs.
- STEP 8** Turn the handlebars as far as they will go in each direction to check for contact between the fork and the neck covers. If contact is detected on either side, slip a rubber fork stop bumper over the stock fork stop "donut" (located on the fork tube) on the affected side and secure it with one of the included nylon zip ties. Adding this extra cushion on the left side is usually not necessary and may interfere with fork lock operation.
- STEP 9** Starting with 5/16"-18 Low Crown Acorn Nut on each end of the stud, tighten all seven fasteners securely.
- STEP 10** Turn handlebars in both directions to their full stop position to make sure that the clutch cable, throttle cables, wiring or any other component of the motorcycle, is not stretched or pinched.

WARNING

ENSURE THAT THE CLUTCH CABLE, THROTTLE CABLES, WIRING OR ANY OTHER COMPONENT OF THE MOTORCYCLE IS NOT PINCHED OR STRETCHED AT ANY POINT WHEN THE HANDLEBARS ARE TURNED TO THEIR FULL STOP POSITION ON EITHER SIDE. STRETCHED OR PINCHED COMPONENTS CAN CAUSE LOSS OF CONTROL THAT COULD RESULT IN SERIOUS INJURY OR DEATH.

NOTICE

Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.