



**CHROME INNER PRIMARY COVER**

**8294**

**PARTS INCLUDED**

- 1 Chrome Inner Primary Cover
- 1 Hardware Kit Containing:
  - 1 Small "L" bracket — Chrome
  - 1 Large "L" bracket — Chrome
  - 1 Plastic Clamp Jaw
  - 2 Foam Pads with Adhesive Back
  - 1 #10"—24 x 2" Button Socket Cap Screw
  - 1 #10 Flat Washer — Chrome
  - 1 1/4"—20 x 1.35" Socket Head Cap Screw
  - 1 1/4" Wave Washer
  - 1 1/4" Flat Washer — Chrome
  - 1 5/16" Flat Washer
  - 4 #6—32 x 1/4" Slotted Flat Machine Screws
  - 1 Standoff Mounting Stud
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**TOOLS SUGGESTED**

Set of Hex Wrenches, Socket Set and Ratchet, Torque Wrench—ft/lbs and in/lbs, Flat Blade Screwdriver

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**


**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let cool.

**WARNING!** YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

-cont.-

**STEP 2**

Install the two "L" brackets using the four supplied #6-32 x 3/8" slotted flat machine screws. With the #10-24 x 2" button socket cap screw and #10 flat washer, **LOOSELY** install the plastic clamp jaw into the corresponding slot in the chrome cover. Place the two foam pads in the orientation shown. PIC 1



**STEP 3**

Remove the stock fasteners from the primary housing at the locations shown. PIC 2 Where the hex bolt was removed from the front of the inner primary case, install the standoff stud with the 5/16" flat washer. **Torque to 18 FOOT POUNDS.**

**STEP 4**

Set the chrome cover into position, and maneuver the plastic clamp jaw so it catches on the lip on the back side of the inner primary housing. Bolt the cover into position using the 1/4"-20 x 1.35 socket head cap screw, 1/4" wave, and flat washers at the front mounting point, and fasten the "L" brackets in place with the stock socket head cap screws removed from the outer primary in Step 2, as shown in PIC.2. **Torque to 96 INCH POUNDS.**

**STEP 5**

With a hex wrench, tighten the 10"-24 x 2" button head closing the plastic clamp jaw on to the lip on the back of the inner primary housing. **TIGHTEN THIS PLASTIC CLAMP SNUG ONLY OR YOU MAY STRIP THE THREADS OUT OF IT.**



*Ride On!*