

INSTALLATION INSTRUCTIONS

RELOCATOR FOR TOUR-PAK® FOR TOURING & TRIKE, BLACK

8956

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

MARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

▲ CAUTION

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right-side Relocator Block
- 1 Left-side Relocator Block

- 1 Hardware Kit, containing:
 - 4 1/4" Flat Washers
 - 4 1/4" Lock Washers
 - 4 1/4"-20 X 1-1/8" Hex Head Screws
 - 4 Cable Ties

YOU WILL ALSO NEED:

1/4" ratchet and sockets, a friend's assistance, and an inch pound (in-lbs) torque wrench

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

▲ WARNING

THE END USER'S SAFETY DEPENDS UPON PROPER INSTALLATION OF THIS PRODUCT. IF A STEP IN THIS SET OF INSTRUCTIONS IS NOT WITHIN YOUR CAPABILITIES OR YOU DO NOT HAVE THE CORRECT TOOLS, HAVE YOUR DEALER PERFORM THE PROCEDURE. IMPROPER INSTALLATION OF THIS PRODUCT COULD RESULT IN DEATH OR SERIOUS INJURY.

NOTICE

AVOID DAMAGE TO THE MOTORCYCLE. PROTECT PAINTED SURFACES WITH A SOFT CLOTH OR BLANKET.

- Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- On the underside of the Tour-Pak®, locate and remove the four hex nuts and washers; set the hardware aside for now, it will be reused.
- STEP 3 Refer to PIC 1. Rest the Tour-Pak® on the seat and have a friend secure it while the Relocator Blocks are installed.
- **STEP 4** Locate the included Relocator Blocks; they are marked "Left Side" and "Right Side".
- Refer to PIC 1. Secure the Blocks to the underside of the Tour-Pak® with the hex nuts and washers removed in STEP 2. Torque the nuts to 60-72 IN-LBS (6.7-8.1 NM).





INSTALLATION INSTRUCTIONS

RELOCATOR FOR TOUR-PAK® FOR TOURING & TRIKE, BLACK

8956

-CONTINUED-

MARNING

STEP 6 Set the Tour-Pak® down on the support frame and align the holes.

There are three sets of holes in the Blocks allowing for three inches of adjustment.

The slot in the support frame allows for an additional one inch of adjustment.

Determine the desired location before securing the Tour-Pak® to the support frame.

STEP 7 Refer to PIC 2. Insert the four included 1/4" Screws, Lock Washers, and

Flat Washers through the support frame and into the Tour-Pak® floor. Leave the screws loose until all four have been started in their threaded

holes.

STEP 8 Torque the screws to 60-72 IN-LBS (6.7-8.1 NM).

ENSURE THAT ALL TOUR-PAK® WIRING IS NOT STRETCHED OUT OR UNDER TENSION. IF NECESSARY, ADJUST THE WIRING SO THAT IT WILL REMAIN CONNECTED DURING OPERATION. USE THE INCLUDED CABLE TIES TO SECURE THE WIRING AWAY FROM MOVING PARTS, PINCH POINTS, OR EXTREME HEAT. KURYAKYN WILL NOT PROVIDE WARRANTY CONVERGE ON ANY ELECTRICAL COMPONENT THAT FALLS DUE TO

COVERAGE ON ANY ELECTRICAL COMPONENT THAT FAILS DUE TO PINCHED, CRIMPED, BROKEN, ABRADED, MELTED, OR FRAYED WIRES.

DO NOT OVERLOAD THE TOUR-PAK®! FOLLOW THE MANUFACTURER'S RECOMMENDED WEIGHT LIMIT. OVER LOADING THE TOUR-PAK® CAN LEAD TO COMPONENT FAILURE WHICH COULD RESULT IN DEATH OR

SERIOUS INJURY.

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE

TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

