



TEARDROP CUSTOM TIE-DOWN BRACKETS 928

FITS: '83-UP FLHT, FLHTC, FLHTCU, FLHR, FLHRC, FLHRS, COMPATIBLE WITH DETACHABLE WINDSHIELD

PARTS INCLUDED

- 2 Teardrop Brackets
- 1 Hardware Kit Including:
 - 4 5/16-18 x 1" Button Head Cap Screw (BSCS)
 - 4 5/16-24 x 1" Button Head Cap Screw (BSCS)
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED


Set of hex wrenches, Torx wrenches, combination wrenches, foot pounds (ft. lbs.) torque wrench.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

STEP 2 Remove the two fasteners on the forks (only remove one side at a time,) which will either be two acorn nuts (see [PIC.1](#)), or two Torx head screws (see [PIC.2](#) next page). Remove the acorn nuts and save to be reinstalled, or remove the Torx screws which will not be reused but will need to be referenced to select the proper screws from the hardware kit.



-cont.-

NOTE

It may not always be possible to reuse the acorn nut, as the stud may not be long enough to thread the acorn nut once the bracket has been installed. If this is the case, it will be necessary to remove the OEM stud and use the screws from the hardware kit to secure the bracket.

STEP 3 Place the tie-down brackets on the fork with the tapered end up (see [PIC.3](#)) placing the holes over on the studs, reuse the acorn nuts removed in STEP 1 to secure the bracket to the forks. On models that had the Torx head screws; there are two different sets of screws included in the hardware kit (a set of fine thread and a set of course thread.) Once you have determined which set of screws will need to be used, place the bracket over the holes and secure with the screws.

STEP 4 Torque the nuts or screws from the previous step to 16-18 ft. lbs.

STEP 5 Repeat STEP 2 through STEP 4 to install the bracket on the other side of the forks.

Ride On!

PIC.2



PIC.3

