




Universal Fat Bar Adaptor – 44257

PARTS INCLUDED:



TOOLS NEEDED: 3/16 hex wrench, 5mm hex wrench, 6mm hex wrench

STEP 1: Remove existing 7/8" handlebars and clamps from your machine.

STEP 2: Mount the bottom clamps using either the M8-1.25 x 20 or 5/16-18 x 3/4 button head cap screws. Tighten to 18 foot pounds of torque.

STEP 3: Place oversize (fat) bar into the bottom clamps. Place top clamp with two M8-1.25 x 35 bolts over bar and finger tighten bolts. Do the same for the other top clamp. Adjust bars to desired position and tighten top clamp bolts to 18 foot pounds of torque.

