



**ATTENTION**

Statements in these instructions that are preceded by the following words are of special significance:

**Warning**

This means there is the possibility of injury to yourself or others.

**Caution**

This means there is the possibility of damage to the motorcycle.

**Note**

*Information of particular importance has been placed in italics.*

**IMPORTANT NOTICE**

Note: Please read the following instructions completely before starting installation!

These shocks can be mounted with the adjuster at the top or bottom. However, we recommend the shocks be mounted with the adjuster at the top for ease of spring adjustment.

Follow instructions in an authorized shop manual or take the motorcycle to a competent dealer.

**Warning**

The motorcycle must be securely blocked to prevent it from tipping over when the shocks are removed. Failure to do so can cause serious damage and/or injury.

The use of lowering blocks on Progressive Suspension shocks is not recommended. Use of a lowering kit may void the warranty or damage the shock/motorcycle.

Progressive Suspension shocks are designed to work on the OEM (Original Equipment) frame and swingarm. Use of these shocks on a frame or swingarm other than OEM may produce an unsatisfactory ride and void the warranty.

Make sure that proper bushings/sleeves are installed in the shocks. Improper bushings/sleeves can cause unsatisfactory and/or unsafe operation (see the instructions packaged with the mounting hardware).

*Be sure to refer to instruction supplements provided in any included mounting hardware*

**Installation**

1. Place a quality jack or sufficient blocks under the motorcycle to securely lift the rear wheel slightly off the ground.
2. Using the correct shop manual for your bike, remove the old shocks and note location of mounting hardware. If additional accessories are installed on your motorcycle, please refer to their mounting instructions for removal to gain access to your shocks.

**Warning**

Lowering your motorcycle will decrease initial ground clearance. The motorcycle will be lower to the ground and care should be taken to avoid bottoming, especially over bumps or in turns. Lowering a motorcycle can change the handling characteristics. Always use extreme caution when riding after a change is made and take time to get accustomed to any handling change.

3. Before installing your new Progressive shocks you need to check the tire to fender clearance, making sure that the tire does not come in contact with the fender. If the rear fender or tire has been changed to anything other than stock, a travel limiter may be required. On some models with side bags or luggage, the bag or luggage mounts may need to be modified to eliminate any interference. Install the shock assemblies onto the motorcycle with the included hardware, note any special instructions in the hardware kit. Tighten bolts / nuts to their proper torque. Check the clearances of the shock to the frame, shock to chain or belt, shock to chain or belt guard and shock to brake caliper and/or linkage. See arrows in Fig 1 , check both sides.

**Caution**

4. Reinstall any accessories removed in accord with their mounting instructions. Make sure accessories do not interfere with the shocks throughout their full travel. If any accessories bolt to the shock mounting points, a careful inspection must be made to insure that they do not bind the shocks in any way. The shock eyes should have a minimum clearance of .02" to insure the eyes are not binding. See Fig 2.

5. Set your ride sag. The proper spring pre-load setting will permit the rear suspension to sag, or compress, approximately 1" inch from full extension. To check sag, take a measurement from the center of the rear axle, straight up to a vertical point on the rear fender or frame with the shocks fully extended. Then take a second measurement using the same points with the rider(s) on the bike. The difference between the two measurements is the ride sag. If the bike is sagging too much, increase the pre-load. These shocks are set at the factory to minimum pre-load.

6. Spring pre-load adjustments are made by turning the Upper (Long) Cover. Turn this adjuster clockwise to increase spring pre-load and counterclockwise to decrease spring pre-load. Above the adjuster, there are 4 grooves, these are pre-load reference marks:

Minimum pre-load = No visible grooves

Maximum pre-load = 4 visible grooves.

Set the pre-load equally on both shocks using these reference marks as your guide. See Fig. 3

**NOTE:** The adjuster is a threaded device, so if you rotate the Adjuster (Upper Cover) fully to the minimum or the maximum setting, you will feel a sudden increase in rotational resistance as you reach the end of the range of adjustment. This sudden increase in resistance is the adjuster tightening against its stop. When you feel this, we recommend that you turn the adjuster back from the stop by approx 1/4 turn. This will facilitate easy adjustments in the future. If the adjuster is tightened firmly against the stop, either at minimum pre-load or maximum, you may have difficulty re-adjusting the pre-load by hand. Should this occur the use of a strap wrench or similar tool will give you the needed leverage to rotate the adjuster away from its stop and return it to normal operation

7. Test ride: If excessive bottoming occurs you need to increase your spring pre-load setting as described above.

8. Then ride and enjoy.....Safely.

Compliment your new shocks with a set of Progressive Suspension fork springs.



Fig 1




Fig 2




Fig 3



**PROGRESSIVE**  
S U S P E N S I O N

## Installation Instructions 444 Series Rear Shocks for Harley Davidson Tri-Glide

**Warning**

1. Read the instructions carefully before installation.  
2. Do not use the shocks if they are damaged or worn.

**Warning**

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

**Ç D E B É Ā Ê**

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

**Ä Å Æ**

Information of particular importance  
has been placed in italics.

### IMPORTANT NOTICE

1. Read the instructions carefully before installation.  
2. Do not use the shocks if they are damaged or worn.

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

3. Do not use the shocks if they are damaged or worn.  
4. Do not use the shocks if they are damaged or worn.

*Be sure to refer to instruction supplements  
provided in any included mounting hardware*

**Warning**

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

**Ç D E B É Ā Ê**

Before installing your new Progressive shocks you should check your exhaust system clearances. The reason for this is Progressive shocks are slightly longer than stock to give you better ground clearance and optimum ride quality, and due to factory assembly tolerances some Trikes may need the exhaust system adjusted to allow for this extra suspension travel. Though most Trikes will not require any adjustment, if while extending your swingarm to install the longer shocks you notice contact - or hear contact - at or around the front of the swingarm or rear pulley housing refer to the "Extended Clearance & Adjustment" section of this instruction for guidance.

**Warning**

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

1. Do not use the shocks if they are damaged or worn.  
2. Do not use the shocks if they are damaged or worn.

Q H&~//;ZŽS! SŽ\* " (f. fP%&ZŽ Ž&fP " Ž12'&1AŽŽSŽ";ZŽ  
 f( &a~;f1fK1(%fP1)1ZŽ& (/<ŽŽ<"S"1;f1f!" ;ZŽ&ZŽ ŽfVZ<&"  
 =Z&f? fZŽ<=Ž? ŽŽf;ZŽ&1AŽŽ~f<;ZŽ\* " (f. fP%&1!1ZŽ2f&  
 \* Ž f&;ZŽ(SSŽ&ZŽ Ž& (/<Ž fVZ<&"!1fP%fP?~1<";?~1<&ZŽ  
 1! \* ŽK1(%fP1E.f<;ZŽ/? Ž" fZ!1fP% )?~1<";?~1<&ZŽ? ZŽ/  
 \* " (f. fK1(%fP1))

5) - !;Ž fP% /fP% ZŽ&SS&ZŽ Ž&fP;ZŽS! SŽ" 1fP~;f1fZŽN  
 ( &fP%ZŽ&1A\* " (f. fP%21<?~1ZŽ SS>~";2Ž<N1A&fP%Žf;"  
 ;ZŽ;2Ž<&!";ZŽ=" /;&\* " (f. ;ZŽ&1A& f;ZŽ1fPŽN? f2;ZŽ  
 SŽŽ' <~<@&Ž~";ZŽ=" ;;" \* N f<;"1C(Z;ZŽ=" /;&" ;ZŽ!1;"1>  
 1Ž" \* \* Žf<Ž'66N. 1;N-&

6) OŽfP%//;ZŽ1Ž1?ZŽ&f<~f<";ZŽ1"\* S' fPŽ &Ž\* " Ž<  
 <(f. fP%ZŽfP%//;f1f)PŽ"1Ž"? ŽfP%ZŽ1fPŽ'f<S(;;fP%ZŽ@A  
 "?~ž1ŽŽ";ZŽQ&Ž: - RS&Ž;f1f;"S! SŽ/>ŽŽ" (1'&%)

, ! fP. /

~9f (\* 1fŽC~f<f&12Ž Ž<? f2>) (1fŽŽ'555: ŽfŽ&Ž'1A&  
 ?ZŽf;ZŽS!Ž' <f&Ž;"~//?~SS!9f ;Ž>)7. SN)/. S"!O&Ž: %&

1"1ZŽA>" (1'O&Ž: ~%S'1Z;ZŽ1fPŽ'f~@A;"1(/>ZŽŽf<;ZŽ  
 1Ž1'&SSŽfP)1'AZ~\* Ž&1Ž\* Žf1" \* ;ZŽŽ~%Ž"!;ZŽif ;"~  
 'Ž;f1/S' fP" f;ZŽ1Žf<Ž)OŽ"1<;2; \* Ž&1Ž\* Žf)E"?;~AZ;ZŽ  
 1fPŽ!!";ZŽ@A f<~?~<;ZŽ=fPŽ? f21fŽf&~f<~f</(%&ZŽ'f<  
 1ŽN Ž&1Ž<Ž? Žf;ZŽ&\* ŽS' fP&12f&Ž" f<~\* Ž&1Ž\* Žf"  
 & (/<=Z' SS!9f ;Ž>)7. SN)/. S&~1;Ž;2'f;ZŽ1f&  
 \* Ž&1Ž\* Žf? ZŽf;ZŽ'f' S!Ž&1Zf&Ž'1" uŽ;/>- <<"1'1Ž<(1Ž  
 SŽŽ' <~H"1<fP%";~12fŽ Ž)7. SN)/. S'&%K1(%fP1)

: S!fP%S!ŽN' <~<@&\* Žf&1Ž\* ~Z=>;(1fP%ZŽ=" ;;" \* K' fP%  
 L" Ž)+ " A&fP% ;ZŽ&1A1" \* ;ZŽ=" ;;" \* ž;(1f;2f&<@&Ž"  
 1'1A' f&Ž;" fP1Ž &Ž&fP%S!ŽN' <~f<1" (f. Ž1/1A' f&Ž;"  
 <Ž1Ž &Ž&fP%S!ŽN' <~>- =" Ž;ZŽ'<@&Žž;2ŽŽ'1ZŽ5%" " Ž&  
 ;ZŽŽ'1ZŽS!ŽN' <1ŽŽŽfŽ\* 1A&  
 fP (\* "S!ŽN' <T'E" " f&ZŽ%" " Ž&  
 ~9f (\* "S!ŽN' <T'5' f&ZŽ%" " Ž&  
 : Ž;ZŽS!ŽN' <ŽC' /> " f=" ;ZŽ&1A& ( &fP%ZŽ&1ŽŽŽfŽ\* 1A&  
 ~& " (1% f&ZK1(%fP1))

2 3 4 5 6 1 ZŽ' <@&Ž f&";2Ž<Ž'<Ž fPŽ& f"> ("1";;ZŽ  
 - <@&Ž K' ? Ž1" Ž1L(/>";ZŽ\* fP (\* "1;ZŽ' ~9f (\* &Ž;fP%  
 > ("? f'1ZŽ'~&<~fP1Ž &Žf1";f1f/1Z& fP Ž' &" (1Ž12;ZŽ  
 Žf<"!;ZŽ1'fPŽ"!~<@&\* Žf)12f&<~fP1Ž &Žf1Ž& fP Žf&  
 ;ZŽ' <@&Ž;f&ZŽfP% fP& f&S' S)U 2Žf> ("1ZŽ;2f&? Ž  
 1Ž" \* \* Žf<;2;~> ("(1f;ZŽ' <@&Ž'1A1" \* ;ZŽ& S'=>~SS!9'  
 V";(1f)12f&? f'1fP;ZŽ &~<@&\* Žf &fP;ZŽ!(;1Ž)B";ZŽ  
 ~<@&Ž f& f&ZŽ<1f' />~%fP&;ZŽ& S'Zf;ZŽ~; \* fP (\* "S!ŽN  
 /' <~1" \* ~9f (\* ž" (\* ~>2' Ž'f1f(/>;1ŽN<@&fP%ZŽS!ŽN' <=>  
 2'f<): 2' (<~;2f&H(1;ZŽ( &Ž"!~& S'?1Žf2"1' &f1;" /? f'  
 %fŽ> ("ZŽfVZ~Ž'Ž'Ž' %Ž;"1";;ZŽ;ZŽ' <@&Ž'~>1" \* f&& S'  
 ~f<1Ž(1fP; " f'1" \* /" SŽ ;f1f

1Ž&1f&ZŽB' ZŽŽ&Ž=" ;;" \* fP% H(1& " fVZ<"; " fP1Ž &Ž>" (1'  
 &fP%S!ŽN' <~& ;fP% &~Z&1f&Z~=" " Ž)

E"? %'1f&Ž'f<~fP@>)))): !Ž>)

L" \* S'f Žf' >" (1fŽŽ' &Ž'1A&? f2~"; 1%ZŽ&Ž: ( &ŽfP f'  
 . " f' (=ZŽ 1;1f&ZŽf1!"1"> (1'1fPŽ!"1A&

Figure 1

: 2' (<Ž

: 2' (<Ž

Figure 2

Figure 3



'1(%fP1)1ZŽ<f1ŽfPŽfP\* Ž&1Ž\* Žf &=Ž? Žf;ZŽ;"S"!;ZŽ  
 1f' f<;ZŽ1Žf<Ž? f2;ZŽ&SSŽ&f1(/>ZŽŽf<~f<;ZŽf' f2'  
 1f&Ž& f;ZŽ=fPŽ& (1'O&Ž: ~%12f&f1ŽfPŽ& (/<=Z)7. SN  
 )/S!"1" \* ~9f (\* 1f&Z!"1";)

OŽŽŽfŽ. ~1A&

Figure 5 ← +ZŽ& , 1Ž' < → "1Ž

