

KICKSTAND PAD – INSTALLATION INSTRUCTIONS

1. Slide the pad onto the kickstand being sure it is as far as it will go.
2. Tighten the setscrew on the side of the pad securely.
3. Recheck the pad and set screw occasionally to be sure that it is secure.

Note: All kickstands are forged or stamped and then the mold parting line is hand ground. Some kickstands may have an excess amount of material on the bottom of the foot. If your pad does not slide completely onto the kickstand you will need to grind or file the bottom of your kickstand foot flat or flush until the pad does slip on completely.