



RADIAL REAR DRIVE PIVOT PLUG

## RADIAL REAR DRIVE PIVOT PLUG

2003-UP 1200 CC BOXERS, 2004-UP K MODELS

61612

### NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future reference.

### NOTICE

It is the end user's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Roland Sands Design will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

### NOTE:

Threadlocker has been pre-applied to the included screw. Threadlocker (Loctite 242 or equivalent) must be re-applied if the Rear Drive Pivot Plug is removed, then reinstalled. Follow the manufacturer's recommendations for proper thread preparation and application.

1. Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **OFF** the ignition.


2. Remove any dirt and debris from the installation area.

3. Refer to **PIC 1**. Use a small flat-blade screwdriver and heavy duty tape (to protect the finish) to remove the existing pivot hole plug. Remove the tape.



4. Refer to **PIC 2**. Locate the Pivot Plug, the Screw, Tapered Plug, and Threaded Plug included in the kit.

5. Insert the Screw through the hole in the Pivot Plug; slip the Tapered Plug over the exposed threads on the back side of the Pivot Plug.



6. Align the Threaded and Tapered Plugs; begin to thread the Screw into the Threaded Plug. Leave the Screw the loose for now.

7. Refer to **PIC 3**. Insert the Pivot Plug assembly into the pivot hole; begin to tighten the Screw; rotate the Plug to your liking, then fully tighten the Screw.



### TIPS FOR PROPER CARE:

- 1 Your new product is made out of anodized aluminum. Anodized aluminum requires special attention when cleaning. Some cleaning products or procedures can actually remove the anodized treatment which will lead to pitting in the aluminum.
- 2 Thoroughly clean the product often with a soft cloth, mild soap and water. Regular cleaning keeps contaminants from building up.
- 3 Rinse thoroughly with FRESH water.
- 4 Use only metal protection products that are formulated for anodized aluminum.
- 5 **DO NOT USE** bleach or chlorides to clean the product.
- 6 **DO NOT USE** products containing abrasives to clean the product. **Never** use steel or brass wool, wire brushes, polishing wheels, rubbing or polishing compounds on the product.
- 7 **DO NOT USE** concentrated alkaline based solutions to clean the product. Many detergents are alkaline based.