

TOOLS NEEDED:

1. POSITION BOTH PIECES ON YOUR SADDLEBAG AS SHOWN IN THE DIAGRAM TO CHECK TO SEE HOW THEY FIT. THEN MARK THE TOP OF THEIR LOCATION WITH SOME MASKING TAPE.
2. USING A MILD SOLVENT, CLEAN THE SADDLEBAG SURFACES WITH A CLEAN LINT FREE RAG.
3. CHECK ALL FOUR PIECES TO MAKE SURE THEY ARE MAKING CONTACT WITH THE SURFACE ON ALL OF THE RUBBER PADS. IF ANY HAVE A SPACE, USE SOME OF THE EXTRA TAPE PADS SUPPLIED TO BUILD UP THE TAPE FOR BETTER CONTACT. BE SURE TO REMOVE THE PROTECTIVE FILM AND SICK TAPE TO TAPE.
4. REMOVE THE BACKING FROM THE TAPE AND LINE UP WITH THE TAPE YOU PUT ON THE BIKE IN STEP 1 AND ATTACH TO THE SADDLEBAG. REPEAT FOR ALL FOUR PIECES.
5. THE TAPE IS PRESSURE SENSITIVE SO ENSURE TO PUT PRESSURE ON THE PART TO ADHERE IT TO THE BIKE.
6. BE SURE TO KEEP THE BIKE IN A COOL DRY PLACE FOR 4 HOURS AFTER ASSEMBLY TO LET THE TAPE CURE.

See Diagram on Below.

