

Copyright© 2014 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.


PART NO. 52-833**WINDSHIELD VENT****HONDA GL1800 2004-2014**

TOOLS NEEDED:	MASKING TAPE FINE TIP MARKER	TAPE MEASURE DRILL	7/16" (11mm) DRILL BIT SABER SAW OR HACK SAW BLADE	UTILITY KNIFE SAND PAPER	5MM ALLEN WRENCH 8MM SOCKET WRENCH
----------------------	---	-------------------------------	---	-------------------------------------	---

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

INSTALLATION:

1. PLACE BIKE ON CENTER STAND AND CLEAN THE FRONT OF THE WINDSHIELD.
2. USING MASKING TAPE, MASK AN AREA ABOUT 10 INCHES WIDE AND ABOUT 4 INCHES HIGH ON THE FRONT OF THE WINDSHIELD. HAVE THE BOTTOM EDGE BE ABOUT 3 INCHES ABOVE THE RUBBER STRIP ON THE FRONT GARNISH WITH THE WINDSHIELD IN THE DOWN POSITION. CENTER THE OTHER WAY.
3. CUT OUT THE TEMPLATE SUPPLIED WITH THESE INSTRUCTIONS. *NOTE: THERE ARE DIMENSIONS IN THE TEMPLATE TO MAKE SURE IT IS PRINTED TO SCALE.*
4. USING A TAPE MEASURE AND A FINE TIP MARKER LOCATE THE CENTER OF THE WINDSHIELD AND DRAW A VERTICAL LINE ON THE MASKING TAPE.
5. MEASURE UP 4 INCHES FROM THE TOP OF THE RUBBER STRIP ON THE FRONT GARNISH AND PUT A MARK ON THE LINE YOU JUST DREW.
6. TAPE THE TEMPLATE TO THE MASKED AREA BY LINING UP THE CENTERLINE WITH THE LINE ON THE TAPE AND KEEPING THE BOTTOM EDGE OF THE TEMPLATE ON THE OTHER MARK. *NOTE: THE WIDER PART OF THE TEMPLATE SHOULD BE ON THE BOTTOM.*
7. REMOVE THE WINDSHIELD FROM THE BIKE AND LAY IT FACE UP ON A CLEAN TOWEL OR CARPET. IT ALSO HELPS TO WRAP A BLOCK OF WOOD WITH A TOWEL AND USE IT TO SUPPORT THE CENTER OF THE WINDSHIELD WHILE CUTTING OUT THE VENT HOLE.
8. USING A DRILL AND A 7/16" BIT DRILL FOUR HOLES THROUGH THE WINDSHIELD AT THE FOUR CROSS MARKS ON THE TEMPLATE.
9. USING A SABER SAW OR HACK SAW BLADE CAREFULLY CUT AROUND THE EDGE OF THE TEMPLATE.
10. TAKE A PIECE OF SAND PAPER AND SMOOTH THE EDGES AND TO REMOVE ANY BURRS FROM CUTTING.
11. USING A 5MM ALLEN WRENCH REMOVE THE TWO SCREWS FROM THE FRONT OF THE NEW WINDSHIELD VENT. PUSH THE TAB ON THE BOTTOM BACK SLIGHTLY AND REMOVE THE FRONT FROM THE BACK OF THE VENT.
12. REMOVE THE TAPE AND CLEAN THE WINDSHIELD.
13. USE THE FACE OF THE VENT TO MAKE SURE THE HOLE YOU CUT IS CORRECT. IT SHOULD FIT FLUSH WITH A LITTLE CLEARANCE AROUND THE EDGES.
14. INSTALL REAR OF VENT FROM THE BACK OF THE WINDSHIELD. HOOK THE TOP IN FIRST AND THEN SNAP THE TAB ON THE BOTTOM BACK TOGETHER.
15. INSTALL HARDWARE. SHOULDER BOLT AND NYLON WASHER FROM THE FRONT AND ACORN NUT ON THE BACK. CAREFULLY TIGHTEN.
16. REINSTALL THE WINDSHIELD ON THE BIKE.



TEMPLATE