

TURN SIGNAL ADAPTER

FOR HONDA CRUISERS – BBP

16-111, 16-113, 16-114

PART NO. 53-439T

TOOLS NEEDED: 8MM SOCKET WRENCH, 4MM ALLEN WRENCH

1. REMOVE THE OLD TURN SIGNAL USING A 8MM SOCKET WRENCH TO REMOVE THE BOLT FROM THE INSIDE OF THE REAR FENDER. YOU MAY NEED TO CUT THE WIRES TO REMOVE THE LIGHT OR UNPLUG THEM FROM UNDERNEATH THE SEAT. REFER TO THE INSTALLATION FOR THE LIGHT YOU WISH TO INSTALL.
2. TAKE THE WIRE LEADS FOR THE NEW LIGHT AND FEED THEM THROUGH THE CENTER OF THE ADAPTER AND OUT THE SIDE HOLE OF BOTH THE ADAPTER AND ADAPTER SPACER.
3. THREAD THE ADAPTER ONTO THE NEW LIGHT. THE ADAPTER ACCEPTS M8 THREADED STUDS.
4. PLACE THE ADAPTER AND ADAPTER SPACER ONTO THE BIKE WHERE THE OLD LIGHT WAS REMOVED. ALIGN THE TAB ON THE SPACER WITH THE SLOT ON THE BIKE. USE THE 4MM ALLEN WRENCH AND THE SUPPLIED M6 BOLT TO BOLT THE ADAPTER TO THE BIKE.
5. TIGHTEN THE LIGHT DOWN AND ADJUST FOR PROPER POSITIONING.