



2017 KAWASAKI Z-900

S1R Slip-On Part # 005-4780406-S1B



BILL OF MATERIALS

2	45mm Spring	005-S45
1	Barrel Clamp 64mm	005-27-64MSH
1	8mm Nylon Lock Nut	005-NN8
1	8x16mm Socket Head Cap Screw	005-SH816
1	Spring Puller	005-SP
1	S1 Clamp	005-2C-S1
1	S1 Clamp Liner	005-2C-S1-A
1	Z900 Muffler Bracket	005-478-B
1	Z900 Muffler Bracket	005-478-B2
1	2017 Kawasaki Z900 Slip Tube	005-47804S
1	Sticker Kit	015-10212
1	Cover Plate	005-478-PLT

INSTALLATION INSTRUCTIONS

1. Make sure the motorcycle is completely cool before installation, and make sure it is secure on a stand or service lift.
2. Remove both OEM heat shields. (Bolts will be re-used with TBR cover plate). **(Reference image 1)**
3. Remove bolt that fastens OEM muffler to passenger foot-peg brace. (This bolt will be re-used with TBR muffler mount). **(Reference image 2)**



4. Next loosen OEM slip on band clamp, and slide muffler back to remove from bike. **(Reference image 3)**
5. Install supplied band clamp and TBR slip tube onto bike. Leave band clamp loose, as some adjusting may be necessary later. **(Reference image 4)**




6. Slide TBR muffler onto TBR slip tube, and install supplied retention springs. **(Reference image 5)**
7. Install the 2 supplied muffler mounting brackets onto OEM muffler mount, using the OEM bolt that was removed in step 3. Leave this bolt loose for now. (The 2 TBR mounting brackets are slightly different. The bracket with the longer bend goes to the inside when mounted... refer to photo below). **(Reference image 6)**



IMPORTANT - PLEASE READ CAREFULLY: We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Also, make sure the bike is secure on a center stand or ideally a service lift during installation. Be sure to save all stock components for possible use later.

WARRANTY: Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

8. Slide muffler clamp over muffler, and fasten to mounting brackets using supplied 8mm bolt & lock nut. **(Reference image 7)**
9. Make sure TBR muffler has sufficient clearance from swing arm. It may be necessary to rotate the slip tube and/or the muffler clamp to get muffler into correct position. Once muffler is in desired position, tighten down both mounting bolts and the band clamp. **(Reference image 8)**



10. Install TBR cover plate using OEM mounting hardware removed in step 2.
11. Double check your work to make sure everything is secure.
12. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.

Care & Cleaning

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

Stainless Header System: Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Titanium Header System: Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Polished Aluminum Canisters: Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

Brushed Aluminum Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

Carbon Fiber Canisters: Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Titanium Mufflers: For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters at the first signs of packing material deterioration. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

NEVER dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.



BILL OF MATERIALS

2	45mm Spring	005-S45
1	Barrel Clamp 64mm	005-27-64MSH
1	8mm Nylon Lock Nut	005-NN8
1	8x16mm Socket Head Cap Screw	005-SH816
1	Spring Puller	005-SP
1	S1 Clamp	005-2C-S1
1	S1 Clamp Liner	005-2C-S1-A
1	Z900 Muffler Bracket	005-478-B
1	Z900 Muffler Bracket	005-478-B2
1	2017 Kawasaki Z900 Slip Tube	005-47804S
1	Sticker Kit	015-10212
1	Cover Plate	005-478-PLT